





Technical Instructions

Thermal release valve TA

Please read through these „technical instructions“ carefully and fully. Work on these devices must only be carried out by qualified personnel.

Meaning of the symbols




-  **Safety instructions**, must be observed!
The disregarding of these instructions can lead to personal injury and / or material damage.
-  **Advice**, the non-compliance with these instructions or the technical data shall lead to the loss of rights under guarantee.
-  **Correct**,
This is how it should be done.
-  **Incorrect**,
This is how it should not be done.

Correct and proper use

The thermal valve TA is used as control SHEV systems. By input command by bursting a thermo bulb or by electrical/pneumatic signal, the energy of a CO_2 bottle suited for SHEV systems is released.

When installing SHEV systems below an installation height of 2,5m from the floor, or from the next access level, suitable devices must be provided to prevent danger to people (crushing and pinching hazard). Follow the corresponding guidelines, rules and norms, e.g. EN 14351 and ASR A1.6. Do not allow children to play with the device or its regulation and/or control devices, including window controls.

General notes

-  The thermal valve is not suited for use in highly corrosive environments (e.g.: thermal spas, waste management industry, etc.).
-  Always close the connections and protect against dirt and humidity.
-  We recommend the use of cutting ring fittings (DIN 3861). Our connection threads are designed for screw-in stud threads R1/8" according to EN 10226. A suitable sealant is recommended.











Figure 1: Thermal valves (symbolically)

-  According to the prEN 12101-9 standard, the TA must be installed inside the SHEV system (e.g. on the mounting, on the curbe of skydome, etc.).
-  The installation height of the TA can be limited in some national standards (e.g. TRVB 125).
-  The TA must not be used to fasten decoration, cables, or other construction products.
-  Do not mount the TA directly over a heat source (stoves, etc.).
-  The volume of the pipeline/device connected to the "SHEV OPEN" output must be at least 6 times greater than the volume of the CO_2 -bottle.
-  When handling this product, always use suitable PPE – personal protective equipment (e.g. protective gloves, safety boots) as protection against sharp and pointed edges, pointed piercing needle, falling objects, and as protection against cold burns.
-  When working on the TA, the work area under the valve must be secured against hazards from falling parts. A suitable PPE must be provided for unavoidable activities below the work area.





Figure 2: connecting electromagnet

Installation




Observe the following before the installation:

- Check the transport box for damage and unauthorized opening.
- The completeness of the delivery.
- Check the valve for transport damages.


-  If incomplete or defective, a complaint must be lodged immediately. The transport box must not be exposed to the elements (e.g.: rain).

When installing the thermal valve, observe the national standards. The thermal valve may not be exposed to extreme temperatures and weather and it is not suited for outdoor storage and assembly. The TA must be mounted to all provided mounting holes, with suitable fastening material, mounted on a firm and stable surface. It is important to ensure that the heat flow, in compliance with the specified angles, can arrive unhindered to the thermo bulb. Connect the respective connections, according to the connection diagram, with suitable screw connections and pipes. Attach pipelines tension-free.


Commissioning

-  See commissioning of the respective TA data sheet.
-  If the CO_2 bottles are not securely fastened, there is a risk that they might catapult during piercing.
-  The thermal valve is not equipped with devices that provide protection against crushing at the SHEV system.

Commissioning of the release lever

-  Before inserting the CO_2 -bottle, check the position of the piercing needle. There is a risk that the CO_2 bottle might be triggered unintentionally and, as a result, the SHEV system might move by accident.

Normal operation



-  When the thermo bulb bursts, glass fragments are created. The position of the TA should be chosen so that, the broken glass poses no danger to the environment (e.g.: vegetable department in the supermarket).

SHEVS release

- **Thermal release:** When the burst temperature is reached the glass bulb, the valve is released.
- **Optional Electrical release:** Possible by applying the nominal voltage (see technical data).
- **Optional Pneumatic release:** Possible by applying the min. control pressure (see technical data).



When released, the screwed-in CO_2 bottle get pierced and the CO_2 will be connected to the output.

Restarting operation/reset


-  Always wear suitable PPE (e.g.: protective gloves, safety boots) when handling this product.
-  Once released, the thermal valve must be restarted by authorised personnel.

Piercing the CO_2 bottles will significantly cool down the CO_2 bottles and all pipes and components in the nearness through which the CO_2 flows. Touching these components for extended periods might cause cold burns.

CO_2 -bottle

-  Only verified CO_2 bottles authorised by us and meeting the requirements of the standards „EN 12205“ or „ADR 2003“ may be used.
-  The CO_2 -bottle must be adjusted for the thermo bulb release temperature and shouldn't be damaged, especially in area of the bursting disc.

Thermo bulb

-  Only thermo bulbs that are authorized by us and approved by national standards may be used.

1. Slowly unscrew the bottle, until you hear a venting noise.
2. Wait until all pressure has been released from the bottle.
3. Fully turn out the bottle.
4. For additional points, refer to commissioning of respective TA data sheet.

Maintenance

Maintenance must be performed

- at least yearly
- and according to the national, legal regulations,
- or if the TA valve has released.



If the TA is no longer functional, it must be replaced completely. It is not permitted to modify or remove any components of the TA. This would impair the safe operation of the TA in which case it may no longer be used.

Possible consequences may include failure to function, re-release of CO_2 , risk of explosion of the CO_2 -bottles.

If necessary, the O-ring, fixings, screw connections, CO_2 bottles and thermo bulbs can be obtained.



Disconnect all power supplies when carrying out maintenance work/troubleshooting on the SHEV system to prevent unintended operation. This can be achieved by turning out the CO_2 bottle. In addition, each additional CO_2 -bottle in the system or the SHEV system Power supply, be interrupted.

Check the following as part of the maintenance:

Check functionality

- piercing needle for damage
- check possible O-ring for damage and regrease it
- connection cable for damage
- function of the cable relief in the connecting plug
- secure attachment of TA
- valve, connections, pipes and CO_2 bottles for corrosion or damage
- CO_2 -bottles for falling below the engraved total weight
- thermo bulbs for damage
- whether the heat flow of the TA is prevented (decoration, shelves, air conditioning, etc.)
- whether there are foreign objects on the TA or its pipeline (decoration, cables, etc.)
- prepare for operation -> see commissioning of the respective data sheet

Malfunction

A malfunction is present if:

- the CO_2 bottles have not been inserted
- the thermo bulb have not been inserted

In the event of a malfunction, arrange for a service by a qualified company immediately.

Functional test TA

In accordance with random sampling procedure, in the event of doubt or if functionality is not given.

- prepare for operation → see commissioning of the respective data sheet
- optional ventilation: apply pressure to the ventilation line OPEN/CLOSE, check whether the SHEV system opens and closes
- destroy thermo bulb



Disassembling the bulb by loosening the bulb screw will damage the valve!

- CO_2 bottle is pierced, SHEV system must open and check valve for leaks (note venting)
- remove the CO_2 bottle and check whether the SHEV system remains open
- optionally, pressure at CLOSE, check whether the SHEV system remains open
- prepare for operation → see commissioning of the respective data sheet
- optionally, pressure at CLOSE, check whether SHEV system closes

Decommissioning/disassembly

Decommissioning/disassembly sequence:

1. remove CO_2 -bottle and separate it from other energy sources
2. remove pipelines from the valve
3. remove valve

Decommissioning/disassembly of TA4

1. remove CO_2 -bottle
2. insert reset tool
3. remove the thermo bulb by loosening the bulb tension screw



Removing the thermo bulb without the reset tool inserted will damage the TA4!

4. unscrew the reset tool
5. closing the bottle screw-in thread
6. remove pipelines from the valve
7. remove valve

Disposal

This product is made of steel, aluminium, non-ferrous metals, plastic and electronic components.



Dispose of this product in observance of the national regulations.